

Perfume

type-A





PF-7101-A · 01 71421 PF-7101-A · 02 71422
T:178 B:80 W:58 H:84.5 cm

PF-7102-A · 01 71431 PF-7102-A · 02 71432
T:178 B:80 W:58 H:84.5 cm



PF-7107-A · 01
72181

PF-7107-A · 02
72182

PF-7107-A · 03
72183



PF-7103-A · 01 71441 PF-7103-A · 02 71442
T:178 B:80 W:58 H:84.5 cm



PF-7104-A · 01 71451 PF-7104-A · 02 71452 PF-7104-A · 03 71453
T:178 B:80 W:58 H:84.5 cm



PF-7107-A · 04 72184 PF-7107-A · 05 72185
T:178 B:80 W:58.5 H:84 cm



PF-7108-A · 01 72191 PF-7108-A · 02 72192



PF-7105-A • 01 71461



PF-7105-A • 02 71462



PF-7105-A • 03 71463



PF-7105-A • 04 71464

T:178 B:80 W:58 H:84.5 cm



PF-7108-A • 03 72193



PF-7108-A • 04 72194



PF-7108-A • 05 72195

T:177 B:80.5 W:58 H:84 cm




PF-7106.S-A • 01 71471



PF-7106.S-A • 02 71472

B:83 W:59 H:80 SH:40~ cm



PF-7109.S-A • 01 72201

B:81 W:59 H:82 cm



PF-7101~PF-7108

腰安定

●PF-7107のみクランクシャフト使用



PF-7107・PF-7108

外部安定



PF-7107・PF-7108・PF-7109S

肩口丸型式



MODE CENTER

株式会社 **モードセンター**

- 本社 〒170-0001 東京都豊島区西巣鴨1-9-6
TEL 03-3918-0411
- 大阪支店 〒530-0014 大阪市北区鶴野町1-3 (安田ビル)
TEL 06-6372-7366
- 名古屋営業所 〒464-0858 名古屋市千種区千種1-15-14
TEL 052-745-7511
- 仙台営業所 〒980-0802 仙台市青葉区二日町3-5 (ハウザービル)
TEL 022-225-7661
- 札幌営業所 〒003-0834 札幌市白石区北郷四条12-10-203
TEL 011-879-5187
- 福岡事務所 〒812-0004 福岡市博多区榎田2-7-14 (サンヴェー空港7号室)
TEL 092-414-6170
- アトリエ 〒354-0013 埼玉県富士見市水谷東3-1-1
TEL 048-471-3511
- 商品管理部 〒354-0002 埼玉県志木市中宗岡5-14-3
TEL 048-487-6787