



Y O G A
m a n n e q u i n s



NSP-7808

T175.0/B84.0/W65.0/H89.0
wide72.0/FootSize23.0



DW:72785/A:72786/R:72787/N:72788/B:73051



NSP-7810

T87.5/B83.0/W64.0/H-
wide84.0/FootSize-
DW:72794/A:72795/R:72796/N:72797/B:73052



NSP-7813

handtop218.0
T176.0/B82.0/W63.5/H87.0
deep80.0/FootSize22.0



DW:72785/A:72786/R:72787/N:72788/B:73051



NSP-7818-A

top150.0
B82.0/W58.0/H88.5
wide85.0~110.0/deep48.0
FootSize23.0



B:73110



NSP-7818-B

B:73111



NSP-7818-C

B:73112



NSP-7819-A

top160.0
B82.0/W58.0/H88.5
wide65.0/deep48.0
FootSize23.0



B:73117



NSP-7819-B

B:73118



NSP-7820

top88.0
B82.0/W58.0/H88.5
wide135.0/deep48.0
FootSize23.0



B:73123



BOT-112

T117.0/W59.0/H87.0
FootSize22.0



10324



BOT-113

T117.0/W59.0/H87.0
FootSize22.0



10325



BOT-114

T119.0/W59.0/H87.0
FootSize22.0



10326



STAND SYSTEM



■ ガラスベース
W40.0/D40.0
56003



■ ガラスベース ストレート
W40.0/D40.0



■ 底安定スタンド
W40.0/D40.0
56006



■ 外部安定スタンド ストレート
W40.0/D40.0



■ スチールベース
W48.0/D48.0
56179



■ スチールベース
W48.0/D48.0
56179



■ 底安定スタンド
W30.0/D30.0
56180

BS SYSTEM



■ 腰安定ベース 大
W40.0/D40.0
56176

HEAD VARIATION



type DW



type A



type R



type N



type B

for

NSP-7808
NSP-7810
NSP-7813



type B[fix]

for

NSP-7818-A
NSP-7818-B
NSP-7818-C
NSP-7819-A
NSP-7819-B
NSP-7820



MODE CENTER

株式会社 モードセンター

本社 〒170-0001 東京都豊島区西巣鴨 1-9-6
TEL 03-3918-0411(代表)

大阪支店 〒530-0014 大阪市北区鶴野町 1-3(安田ビル)
TEL 06-6372-7366(代表)

名古屋営業所 〒464-0858 名古屋市中千種区千種 1-15-14
TEL 052-745-7511(代表)

仙台営業所 〒980-0802 仙台市青葉区二日町 3-5(ハウザービル)
TEL 022-225-7661(代表)

札幌事務所 〒003-0834 札幌市白石区北郷四条 12-10-10-203
TEL 011-879-5187(代表)

福岡事務所 〒812-0004 福岡市博多区榎田 2-7-14(サンビュー空港7号室)
TEL 092-414-6170(代表)

商品管理センター 〒354-0043 埼玉県入間郡三芳町竹間沢 209-1
TEL 049-211-0001(代表)

アトリエ 〒354-0013 埼玉県富士見市水谷東 3-1-1
TEL 048-471-3522(代表)